



# External view of LCMR200


## LCMR200 Module connection and installation

Front\* cable extraction

### LCMR200-F\*\*




| Module type | LA    | LB  |
|-------------|-------|-----|
| LCMR200-F2  | 199.4 | 183 |
| LCMR200-F3  | 299.4 | 283 |
| LCMR200-F5  | 499.4 | 483 |
| LCMR200-F10 | 999.4 | 983 |




## Linear module

Front\* cable extraction


### LCMR200-F2



### LCMR200-F3



### LCMR200-F5



### LCMR200-F10

